

◆ CALL FORWARDING INSTRUCTIONS ◆

SoundPoint® IP 670

To enable call forwarding:

1. From the idle screen, press the Forward soft key.
2. Select the forwarding type you want to enable:
 - Always—To forward all incoming calls.
 - No Answer—To forward all unanswered incoming calls.
 - Busy—To forward calls that arrive when you are already in a call.
3. Enter a number to forward calls to. For No Answer, enter the number of rings before forwarding.
4. Press the Enable soft key.

To disable call forwarding:

1. From the idle screen, press the Forward soft key.
2. Select the forwarding type you want to disable.
3. Press the Disable soft key

For questions regarding call forwarding,
visit www.specialtyanswering.com,
or call us at 1-866-688-8912.